



European Network of
Transmission System Operators
for Electricity

CONTINGENCY PROFILE SPECIFICATION

2024-10-16

ICTC APPROVED
VERSION 2.3.1

1 Copyright notice:

2 **Copyright © ENTSO-E. All Rights Reserved.**

3 This document and its whole translations may be copied and furnished to others, and derivative
4 works that comment on or otherwise explain it or assist in its implementation may be prepared,
5 copied, published and distributed, in whole or in part, without restriction of any kind, provided
6 that the above copyright notice and this paragraph are included on all such copies and
7 derivative works. However, this document itself may not be modified in any way, except for
8 literal and whole translation into languages other than English and under all circumstances, the
9 copyright notice or references to ENTSO-E may not be removed.

10 This document and the information contained herein is provided on an "as is" basis.

11 **ENTSO-E DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT**
12 **LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT**
13 **INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR**
14 **FITNESS FOR A PARTICULAR PURPOSE.**

15 **This document is maintained by the ENTSO-E CIM WG. Comments or remarks are to be**
16 **provided at cim@entsoe.eu**

17 **NOTE CONCERNING WORDING USED IN THIS DOCUMENT**

18 The force of the following words is modified by the requirement level of the document in which
19 they are used.

- 20 • SHALL: This word, or the terms "REQUIRED" or "MUST", means that the definition is an
21 absolute requirement of the specification.
- 22 • SHALL NOT: This phrase, or the phrase "MUST NOT", means that the definition is an
23 absolute prohibition of the specification.
- 24 • SHOULD: This word, or the adjective "RECOMMENDED", means that there may exist valid
25 reasons in particular circumstances to ignore a particular item, but the full implications must
26 be understood and carefully weighed before choosing a different course.
- 27 • SHOULD NOT: This phrase, or the phrase "NOT RECOMMENDED", means that there may
28 exist valid reasons in particular circumstances when the particular behaviour is acceptable
29 or even useful, but the full implications should be understood and the case carefully weighed
30 before implementing any behaviour described with this label.
- 31 • MAY: This word, or the adjective "OPTIONAL", means that an item is truly optional.

32

Revision History

Version	Date	Paragraph	Comments
1.0.0	2021-03-22		Document for SOC approval
2.0.0	2021-10-12		For CIM EG review. Additional information is added to exceptional contingency. The combination between assessed element and contingency is modelled.
2.0.0	2022-02-16		For CIM EG review. Additional information is added to exceptional contingency. The combination between assessed element and contingency is modelled. For SOC approval
2.1.0	2022-09-21		For SOC approval
2.2.0	2023-03-24		For review
2.2.0	2023-04-20		For ICTC approval.
2.3.0-alpha	2024-03-20		For CIM WG review.
2.3.1-alpha	2024-09-07		For CIM WG review.

34	CONTENTS		
35	Copyright notice:.....		2
36	Revision History.....		3
37	CONTENTS		4
38	1 Introduction		6
39	2 Application profile specification		6
40	2.1 Version information		6
41	2.2 Constraints naming convention		6
42	2.3 Profile constraints		7
43	2.4 Metadata.....		10
44	2.4.1 Constraints		10
45	2.4.2 Reference metadata		11
46	3 Detailed Profile Specification		11
47	3.1 General.....		11
48	3.2 (abstract) Contingency		11
49	3.3 (abstract) ContingencyElement		12
50	3.4 ContingencyEquipment		12
51	3.5 (abstract) Equipment root class.....		13
52	3.6 (NC) ExceptionalContingency		13
53	3.7 (abstract) IdentifiedObject root class		14
54	3.8 (NC) OrdinaryContingency		14
55	3.9 (NC) OutOfRangeContingency		14
56	3.10 (abstract) SimulationEvents root class		15
57	3.11 (abstract,NC) SystemOperator root class		15
58	3.12 (NC) ContingencyConditionKind enumeration.....		15
59	3.13 ContingencyEquipmentStatusKind enumeration		15
60	3.14 UnitMultiplier enumeration		16
61	3.15 UnitSymbol enumeration		16
62	3.16 PerCent datatype		17
63	3.17 Boolean primitive		17
64	3.18 Float primitive		17
65	3.19 String primitive.....		17
66	Annex A (informative): Sample data		18
67	A.1 General.....		18
68	A.2 Sample instance data.....		18
69			
70	List of figures		
71	Figure 1 – Class diagram ContingencyProfile::ContingencyProfile		11
72			
73	List of tables		
74	Table 1 – Attributes of ContingencyProfile::Contingency		11
75	Table 2 – Association ends of ContingencyProfile::Contingency with other classes		12

76	Table 3 – Attributes of ContingencyProfile::ContingencyElement	12
77	Table 4 – Association ends of ContingencyProfile::ContingencyElement with other	
78	classes	12
79	Table 5 – Attributes of ContingencyProfile::ContingencyEquipment.....	13
80	Table 6 – Association ends of ContingencyProfile::ContingencyEquipment with other	
81	classes	13
82	Table 7 – Attributes of ContingencyProfile::ExceptionalContingency	13
83	Table 8 – Association ends of ContingencyProfile::ExceptionalContingency with other	
84	classes	13
85	Table 9 – Attributes of ContingencyProfile::IdentifiedObject	14
86	Table 10 – Attributes of ContingencyProfile::OrdinaryContingency	14
87	Table 11 – Association ends of ContingencyProfile::OrdinaryContingency with other	
88	classes	14
89	Table 12 – Attributes of ContingencyProfile::OutOfRangeContingency	15
90	Table 13 – Association ends of ContingencyProfile::OutOfRangeContingency with	
91	other classes	15
92	Table 14 – Literals of ContingencyProfile::ContingencyConditionKind	15
93	Table 15 – Literals of ContingencyProfile::ContingencyEquipmentStatusKind	15
94	Table 16 – Literals of ContingencyProfile::UnitMultiplier	16
95	Table 17 – Literals of ContingencyProfile::UnitSymbol	16
96	Table 18 – Attributes of ContingencyProfile::PerCent.....	17
97		

98 1 Introduction

99 The contingency profile is a profile to exchange a list of contingencies.

100 A contingency is the identified and possible or already occurred fault of an element, including
101 not only the transmission system elements, but also significant grid users and distribution
102 network elements if relevant for the transmission system operational security.¹

103 The contingencies are input data for security analysis.

104 Preventive remedial actions may be applied in the base case and consequently in each
105 contingency case since each contingency is applied on top of the base case with the
106 consideration of all applied preventive remedial actions. There is no explicit association
107 between preventive remedial actions and contingencies because of the definition of preventive
108 remedial action. Curative remedial actions may be applied to the contingencies they are
109 associated with and these association are the ones that is included in this profile. It is required
110 to have an explicit list of assessed elements that relate to a given contingency. Only these
111 assessed elements will be scanned when the contingency is simulated. Therefore, the profile
112 restricts that at least one assessed element shall be scanned for a given contingency. The
113 profile allows that contingencies can be associated to a given region, which indicates in which
114 region these contingencies are studied. For instance, in CSA process normally the region has
115 the meaning of a capacity calculation region.

116 2 Application profile specification

117 2.1 Version information

118 The content is generated from UML model file CIM17-2_CGMES31v01_PROF-
119 20v02_NC23v65_MS10v01_DES10v01.eap.

120 This edition is based on the IEC 61970 UML version 'IEC61970CIM17v40', dated '2020-08-24'.

- 121 - Title: Contingency Vocabulary
- 122 - Keyword: CO
- 123 - Description: This vocabulary is describing the contingency profile.
- 124 - Version IRI: <https://ap-voc.cim4.eu/Contingency/2.3>
- 125 - Version info: 2.3.1
- 126 - Prior version: <http://entsoe.eu/ns/CIM/Contingency-EU/2.2>
- 127 - Conforms to: urn:iso:std:iec:61970-600-2:ed-1|urn:iso:std:iec:61970-301:ed-
128 7:amd1|file://iec61970cim17v40_iec61968cim13v13a_iec62325cim03v17a.eap|urn:iso:
129 std:iec:61970-401:draft:ed-1|urn:iso:std:iec:61970-501:draft:ed-
130 2|file://CIM100_CGMES31v01_501-20v02_NC23v62_MM10v01.eap
- 131 - Identifier: urn:uuid:8947de1c-6e53-4f1f-82c3-99ef118db9eb

132

133 2.2 Constraints naming convention

134 The naming of the rules shall not be used for machine processing. The rule names are just a
135 string. The naming convention of the constraints is as follows.

136 "{rule.Type}:{rule.Standard}:{rule.Profile}:{rule.Property}:{rule.Name}"

137 where

¹ [SOURCE: CACM art.2.10]

- 138 rule.Type: C – for constraint; R – for requirement
- 139 rule.Standard: the number of the standard e.g. 301 for 61970-301, 456 for 61970-456, 13 for
140 61968-13. 61970-600 specific constraints refer to 600 although they are related to one or
141 combination of the 61970-450 series profiles. For NC profiles, NC is used.
- 142 rule.Profile: the abbreviation of the profile, e.g. TP for Topology profile. If set to “ALL” the
143 constraint is applicable to all IEC 61970-600 profiles.
- 144 rule.Property: for UML classes, the name of the class, for attributes and associations, the name
145 of the class and attribute or association end, e.g. EnergyConsumer, IdentifiedObject.name, etc.
146 If set to “NA” the property is not applicable to a specific UML element.
- 147 rule.Name: the name of the rule. It is unique for the same property.
- 148 Example: C:600:ALL:IdentifiedObject.name:stringLength

149 2.3 Profile constraints

150 This clause defines requirements and constraints that shall be fulfilled by applications that
151 conform to this document.

152 This document is the master for rules and constraints tagged "NC". For the sake of self-
153 containment, the list below also includes a copy of the relevant rules from IEC 61970-452,
154 tagged "452".

- 155 • C:452:ALL:NA:datatypes

156 According to 61970-501, datatypes are not exchanged in the instance data. The
157 UnitMultiplier is 1 in cases none value is specified in the profile.

- 158 • R:452:ALL:NA:exchange

159 Optional and required attributes and associations must be imported and exported if they
160 are in the model file prior to import.

- 161 • R:452:ALL:NA:exchange1

162 If an optional attribute does not exist in the imported file, it does not have to be exported
163 in case exactly the same data set is exported, i.e. the tool is not obliged to automatically
164 provide this attribute. If the export is resulting from an action by the user performed after
165 the import, e.g. data processing or model update the export can contain optional
166 attributes.

- 167 • R:452:ALL:NA:exchange2

168 In most of the profiles the selection of optional and required attributes is made so as to
169 ensure a minimum set of required attributes without which the exchange does not fulfil
170 its basic purpose. Business processes governing different exchanges can require
171 mandatory exchange of certain optional attributes or associations. Optional and required
172 attributes and associations shall therefore be supported by applications which claim
173 conformance with certain functionalities of the IEC 61970-452. This provides flexibility
174 for the business processes to adapt to different business requirements and base the
175 exchanges on IEC 61970-452 compliant applications.

- 176 • R:452:ALL:NA:exchange3

- 177 An exporter may, at his or her discretion, produce a serialization containing additional
178 class data described by the CIM Schema but not required by this document provided
179 these data adhere to the conventions established in Clause 5.
- 180 • R:452:ALL:NA:exchange4
- 181 From the standpoint of the model import used by a data recipient, the document
182 describes a subset of the CIM that importing software shall be able to interpret in order
183 to import exported models. Data providers are free to exceed the minimum requirements
184 described herein as long as their resulting data files are compliant with the CIM Schema
185 and the conventions established in Clause 5. The document, therefore, describes
186 additional classes and class data that, although not required, exporters will, in all
187 likelihood, choose to include in their data files. The additional classes and data are
188 labelled as required (cardinality 1..1) or as optional (cardinality 0..1) to distinguish them
189 from their required counterparts. Please note, however, that data importers could
190 potentially receive data containing instances of any and all classes described by the
191 CIM Schema.
- 192 • R:452:ALL:NA:cardinality
- 193 The cardinality defined in the CIM model shall be followed, unless a more restrictive
194 cardinality is explicitly defined in this document. For instance, the cardinality on the
195 association between VoltageLevel and BaseVoltage indicates that a VoltageLevel shall
196 be associated with one and only one BaseVoltage, but a BaseVoltage can be associated
197 with zero to many VoltageLevels.
- 198 • R:452:ALL:NA:associations
- 199 Associations between classes referenced in this document and classes not referenced
200 here are not required regardless of cardinality.
- 201 • R:452:ALL:IdentifiedObject.name:rule
- 202 The attribute “name” inherited by many classes from the abstract class IdentifiedObject
203 is not required to be unique. It must be a human readable identifier without additional
204 embedded information that would need to be parsed. The attribute is used for purposes
205 such as User Interface and data exchange debugging. The MRID defined in the data
206 exchange format is the only unique and persistent identifier used for this data exchange.
207 The attribute IdentifiedObject.name is, however, always required for CoreEquipment
208 profile and Short Circuit profile.
- 209 • R:452:ALL:IdentifiedObject.description:rule
- 210 The attribute “description” inherited by many classes from the abstract class
211 IdentifiedObject must contain human readable text without additional embedded
212 information that would need to be parsed.
- 213 • R:452:ALL:NA:uniqueIdentifier
- 214 All IdentifiedObject-s shall have a persistent and globally unique identifier (Master
215 Resource Identifier - mRID).
- 216 • R:452:ALL:NA:unitMultiplier
- 217 For exchange of attributes defined using CIM Data Types (ActivePower, Susceptance,
218 etc.) a unit multiplier of 1 is used if the UnitMultiplier specified in this document is “none”.
- 219 • C:452:ALL:IdentifiedObject.name:stringLength

- 220 The string IdentifiedObject.name has a maximum of 128 characters.
- 221 • C:452:ALL:IdentifiedObject.description:stringLength
- 222 The string IdentifiedObject.description is maximum 256 characters.
- 223 • C:452:ALL:NA:float
- 224 An attribute that is defined as float (e.g. has a type Float or a type which is a Datatype
225 with .value attribute of type Float) shall support ISO/IEC 60559:2020 for floating-point
226 arithmetic using single precision floating point. A single precision float supports 7
227 significant digits where the significant digits are described as an integer, or a decimal
228 number with 6 decimal digits. Two float values are equal when the significant with 7
229 digits are identical, e.g. 1234567 is equal 1.234567E6 and so are 1.2345678 and
230 1.234567E0.
- 231 • R:NC:ALL:Region:reference
- 232 The reference to the Region is normally a reference to the capacity calculation region,
233 which is identified by “Y” EIC code of the capacity calculation region.
- 234 • R:NC:ALL:SystemOperator:reference
- 235 The reference to the System Operator is normally identified by “X” EIC code of TSO.
- 236 • C:NC:CO:ContingencyEquipment.contingentStatus:allowedValues
- 237 The allowed value for the ContingencyEquipment.contingentStatus is
238 ContingencyEquipmentStatusKind.outOfService.
- 239 • C:NC:CO:Contingency.ContingencyElement:outOfRangeAndExceptional
- 240 The multiplicity of the association end Contingency.ContingencyElement is restricted to
241 2..* for both OutOfRangeContingency and ExceptionalContingency.
- 242 • R:NC:ALL:NA:serialization
- 243 The profiles are defined in the EnterpriseArchitect application and have multiple artifacts
244 that describe them. The main artifacts are:
- 245 1) the EAP file (EnterpriseArchitect project file),
246 2) the profiles’ specification document and
247 3) the application profiles (RDFS and SHACL).
- 248 Due to the complexity of the profiles, there are various cross profile associations that,
249 from profiling and profile maintenance point of view, it is not practical to include the
250 complete inheritance structure in all profiles. If this is done the documentation provided
251 for all profiles would also include duplicated information on the description of classes
252 defined in other profiles. The following cases are often observed in profiles:
- 253 ○ Case 1: An association end refers to an abstract class
254 ○ Case 2: An abstract class (stereotyped with “Description”) has an association
255 (direction to another class)
256 ○ Case 3: An abstract class (not stereotyped with “Description”) has an
257 association (direction to another class)
258 ○ Case 4: An abstract class has attributes and subclasses are not in the profile
- 259 In all cases, the datasets shall only include the subtypes of the abstract classes with
260 the related properties (i.e. association or attributes) defined in the profile. The
261 information is taken from either canonical model or the profiles where complete

262 (expected) inheritance structure for the related abstract class is described. SHACL
263 based constraints include constraints only for the concrete classes that are subtypes of
264 the abstract class in the profile, and this can be used to inform which are the concrete
265 classes expected in a dataset that conforms to this profile.

266 It should be taken into account that this approach deviates from MVAL5 (IEC 61970-
267 600-1:2021), which creates multiple inheritance at serialization. For instance, with this
268 more explicit exchange the serialization of the association between abstract class
269 Equipment and abstract class Circuit for a PowerTransformer will be serialized as
270 follows:

271 o for association

```
272 <cim:PowerTransformer rdf:about="_c328f787-bc17-47ad-a59f-6ba7133340d0">
```

```
273   <nc:Equipment.Circuit rdf:resource="#_9ced16ac-d076-4ef9-a241-a998a579e77b"/>
```

```
274 </cim:PowerTransformer>
```

275 o for attribute

```
276 <cim:ACLineSegment rdf:about="_04f681aa-6999-4fb3-9775-aca5eb7ceff">
```

```
277   <cim:Equipment.inService>true</cim:Equipment.inService>
```

```
278 </cim:ACLineSegment>
```

279 The usage of rdf:ID or rdf:about depends on the stereotype of the class. rdf:about is
280 used if the class has the stereotype "Description".

281 An example of not allowed serialization, as the Equipment is an abstract class

```
282 <cim:Equipment rdf:about="_c328f787-bc17-47ad-a59f-6ba7133340d0">
```

```
283   <nc:Equipment.Circuit rdf:resource="#_9ced16ac-d076-4ef9-a241-a998a579e77b"/>
```

```
284 </cim:Equipment>
```

285

286 2.4 Metadata

287 ENTSO-E agreed to extend the header and metadata definitions by IEC 61970-552 Ed2. This
288 new header definitions rely on W3C recommendations which are used worldwide and are
289 positively recognised by the European Commission. The new definitions of the header mainly
290 use Provenance ontology (PROV-O), Time Ontology and Data Catalog Vocabulary (DCAT). The
291 global new header applicable for this profile is included in the metadata and document header
292 specification document.

293 The header vocabulary contains all attributes defined in IEC 61970-552. This is done only for
294 the purpose of having one vocabulary for header and to ensure transition for data exchanges
295 that are using IEC 61970-552:2016 header. This profile does not use IEC 61970-552:2016
296 header attributes and relies only on the extended attributes.

297 2.4.1 Constraints

298 The identification of the constraints related to the metadata follows the same convention for
299 naming of the constraints as for profile constraints.

- 300 • R:NC:ALL:wasAttributedTo:usage

301 The prov:wasAttributedTo should normally be the “X” EIC code of the actor or their URI
302 (prov:Agent).

303


304 **2.4.2 Reference metadata**

305 The header defined for this profile requires availability of a set of reference metadata. For
306 instance, the attribute prov:wasGeneratedBy requires a reference to an activity which produced
307 the model or the related process. The activities are defined as reference metadata and their
308 identifiers are referenced from the header to enable the receiving entity to retrieve the “static”
309 (reference) information that it is not modified frequently. This approach imposes a requirement
310 that both the sending entity and the receiving entity have access to a unique version of the
311 reference metadata. Therefore, each business process shall define which reference metadata
312 is used and where it is located.

313 **3 Detailed Profile Specification**

314 **3.1 General**

315 This package contains contingency profile.



316

317 **Figure 1 – Class diagram ContingencyProfile::ContingencyProfile**

318 Figure 1: The diagram contains the main classes used in the profile.

319 **3.2 (abstract) Contingency**

320 Inheritance path = [IdentifiedObject](#)

321 An event threatening system reliability, consisting of one or more contingency elements.

322 Table 1 shows all attributes of Contingency.

323

Table 1 – Attributes of ContingencyProfile::Contingency

name	mult	type	description
normalProbability	0..1	PerCent	(NC) Normal probability of the occurrence of the contingency based on normal operational condition. The value is used as the default if the probability is missing. The allowed value range is [0,100].

name	mult	type	description
normalMustStudy	1..1	Boolean	(NC) Specifies the requirement of study the contingency under normal operating conditions. True means the contingency must be study in a normal scenario. False means that the contingency does not need to be included in the scenario. This is the default value if mustStudy is missing.
description	0..1	String	inherited from: IdentifiedObject
mRID	1..1	String	inherited from: IdentifiedObject
name	0..1	String	inherited from: IdentifiedObject

324

325 Table 2 shows all association ends of Contingency with other classes.

326

Table 2 – Association ends of ContingencyProfile::Contingency with other classes

mult from	name	mult to	type	description
0..*	EquipmentOperator	0..1	SystemOperator	(NC) System operator that is operating the equipment that is being run a contingency on.
0..1	SimulationEvents	0..1	SimulationEvents	(NC) Simulation event for a contingency.

327

3.3 (abstract) ContingencyElement329 Inheritance path = [IdentifiedObject](#)330 An element of a system event to be studied by contingency analysis, representing a change in
331 status of a single piece of equipment.

332 Table 3 shows all attributes of ContingencyElement.

333

Table 3 – Attributes of ContingencyProfile::ContingencyElement

name	mult	type	description
description	0..1	String	inherited from: IdentifiedObject
mRID	1..1	String	inherited from: IdentifiedObject
name	0..1	String	inherited from: IdentifiedObject

334

335 Table 4 shows all association ends of ContingencyElement with other classes.

336

Table 4 – Association ends of ContingencyProfile::ContingencyElement with other classes

337

mult from	name	mult to	type	description
1..*	Contingency	1..1	Contingency	A contingency element belongs to one contingency.

338

3.4 ContingencyEquipment340 Inheritance path = [ContingencyElement](#) : [IdentifiedObject](#)341 Equipment whose in service status is to change, such as a power transformer or AC line
342 segment.

343 Table 5 shows all attributes of ContingencyEquipment.

344

Table 5 – Attributes of ContingencyProfile::ContingencyEquipment

name	mult	type	description
contingentStatus	1..1	ContingencyEquipmentStatusKind	The status for the associated equipment when in the contingency state. This status is independent of the case to which the contingency is originally applied, but defines the equipment status when the contingency is applied.
description	0..1	String	inherited from: IdentifiedObject
mRID	1..1	String	inherited from: IdentifiedObject
name	0..1	String	inherited from: IdentifiedObject

345

346

Table 6 shows all association ends of ContingencyEquipment with other classes.

347

Table 6 – Association ends of ContingencyProfile::ContingencyEquipment with other classes

348

mult from	name	mult to	type	description
0..*	Equipment	1..1	Equipment	The single piece of equipment to which to apply the contingency.
1..*	Contingency	1..1	Contingency	inherited from: ContingencyElement

349

350

3.5 (abstract) Equipment root class

351

The parts of a power system that are physical devices, electronic or mechanical.

352

3.6 (NC) ExceptionalContingency

353

Inheritance path = [Contingency](#) : [IdentifiedObject](#)

354

Exceptional contingency means the simultaneous occurrence of multiple contingencies with a common cause.

355

356

Table 7 shows all attributes of ExceptionalContingency.

357

Table 7 – Attributes of ContingencyProfile::ExceptionalContingency

name	mult	type	description
kind	0..1	ContingencyConditionKind	(NC) Defines the kind of relevance and criteria of application of the exceptional contingency.
normalProbability	0..1	PerCent	(NC) inherited from: Contingency
normalMustStudy	1..1	Boolean	(NC) inherited from: Contingency
description	0..1	String	inherited from: IdentifiedObject
mRID	1..1	String	inherited from: IdentifiedObject
name	0..1	String	inherited from: IdentifiedObject

358

359

Table 8 shows all association ends of ExceptionalContingency with other classes.

360

Table 8 – Association ends of ContingencyProfile::ExceptionalContingency with other classes

361

mult from	name	mult to	type	description
0..*	EquipmentOperator	0..1	SystemOperator	(NC) inherited from: Contingency
0..1	SimulationEvents	0..1	SimulationEvents	(NC) inherited from: Contingency

362

363 **3.7 (abstract) IdentifiedObject root class**364 This is a root class to provide common identification for all classes needing identification and
365 naming attributes.

366 Table 9 shows all attributes of IdentifiedObject.

367 **Table 9 – Attributes of ContingencyProfile::IdentifiedObject**

name	mult	type	description
description	0..1	String	The description is a free human readable text describing or naming the object. It may be non unique and may not correlate to a naming hierarchy.
mRID	1..1	String	Master resource identifier issued by a model authority. The mRID is unique within an exchange context. Global uniqueness is easily achieved by using a UUID, as specified in RFC 4122, for the mRID. The use of UUID is strongly recommended. For CIMXML data files in RDF syntax conforming to IEC 61970-552, the mRID is mapped to rdf:ID or rdf:about attributes that identify CIM object elements.
name	0..1	String	The name is any free human readable and possibly non unique text naming the object.

368

369 **3.8 (NC) OrdinaryContingency**370 Inheritance path = [Contingency](#) : [IdentifiedObject](#)

371 Ordinary contingency means the occurrence of a contingency of a single branch or injection.

372 Table 10 shows all attributes of OrdinaryContingency.

373 **Table 10 – Attributes of ContingencyProfile::OrdinaryContingency**

name	mult	type	description
normalProbability	0..1	PerCent	(NC) inherited from: Contingency
normalMustStudy	1..1	Boolean	(NC) inherited from: Contingency
description	0..1	String	inherited from: IdentifiedObject
mRID	1..1	String	inherited from: IdentifiedObject
name	0..1	String	inherited from: IdentifiedObject

374

375 Table 11 shows all association ends of OrdinaryContingency with other classes.

376 **Table 11 – Association ends of ContingencyProfile::OrdinaryContingency with other
377 classes**

mult from	name	mult to	type	description
0..*	EquipmentOperator	0..1	SystemOperator	(NC) inherited from: Contingency
0..1	SimulationEvents	0..1	SimulationEvents	(NC) inherited from: Contingency

378

379 **3.9 (NC) OutOfRangeContingency**380 Inheritance path = [Contingency](#) : [IdentifiedObject](#)381 Out of range means the simultaneous occurrence of multiple contingencies without a common
382 cause, or a loss of power generating modules with a total loss of generation capacity exceeding
383 the reference incident.

384 Table 12 shows all attributes of OutOfRangeContingency.

385 **Table 12 – Attributes of ContingencyProfile::OutOfRangeContingency**

name	mult	type	description
normalProbability	0..1	PerCent	(NC) inherited from: Contingency
normalMustStudy	1..1	Boolean	(NC) inherited from: Contingency
description	0..1	String	inherited from: IdentifiedObject
mRID	1..1	String	inherited from: IdentifiedObject
name	0..1	String	inherited from: IdentifiedObject

386

387 Table 13 shows all association ends of OutOfRangeContingency with other classes.

388 **Table 13 – Association ends of ContingencyProfile::OutOfRangeContingency with other**
389 **classes**

mult from	name	mult to	type	description
0..*	EquipmentOperator	0..1	SystemOperator	(NC) inherited from: Contingency
0..1	SimulationEvents	0..1	SimulationEvents	(NC) inherited from: Contingency

390

391 **3.10 (abstract) SimulationEvents root class**

392 A configuration or a set of events executed during a simulation.

393 **3.11 (abstract,NC) SystemOperator root class**

394 System operator.

395 **3.12 (NC) ContingencyConditionKind enumeration**

396 Kinds of occurrence criteria of application.

397 Table 14 shows all literals of ContingencyConditionKind.

398 **Table 14 – Literals of ContingencyProfile::ContingencyConditionKind**

literal	value	description
geographicalLocation		Permanent occurrence factor which is specific geographical location.
design		Permanent occurrence factor which is design condition.
environmental		Temporary occurrence factor which is weather or environmental condition (e.g. storm).
operational		Temporary occurrence factor which is operational condition.
malfunction		Temporary occurrence factor which is life time or generic malfunction affecting the risk of failure condition.

399

400 **3.13 ContingencyEquipmentStatusKind enumeration**

401 Indicates the state which the contingency equipment is to be in when the contingency is applied.

402 Table 15 shows all literals of ContingencyEquipmentStatusKind.

403 **Table 15 – Literals of ContingencyProfile::ContingencyEquipmentStatusKind**

literal	value	description
inService		The equipment is to be put into service.
outOfService		The equipment is to be taken out of service.

404

405 **3.14 UnitMultiplier enumeration**

406 The unit multipliers defined for the CIM. When applied to unit symbols, the unit symbol is
407 treated as a derived unit. Regardless of the contents of the unit symbol text, the unit symbol
408 shall be treated as if it were a single-character unit symbol. Unit symbols should not contain
409 multipliers, and it should be left to the multiplier to define the multiple for an entire data type.

410 For example, if a unit symbol is "m2Pers" and the multiplier is "k", then the value is $k(m^{**2}/s)$,
411 and the multiplier applies to the entire final value, not to any individual part of the value. This
412 can be conceptualized by substituting a derived unit symbol for the unit type. If one imagines
413 that the symbol "P" represents the derived unit "m2Pers", then applying the multiplier "k" can
414 be conceptualized simply as "kP".

415 For example, the SI unit for mass is "kg" and not "g". If the unit symbol is defined as "kg", then
416 the multiplier is applied to "kg" as a whole and does not replace the "k" in front of the "g". In
417 this case, the multiplier of "m" would be used with the unit symbol of "kg" to represent one gram.
418 As a text string, this violates the instructions in IEC 80000-1. However, because the unit symbol
419 in CIM is treated as a derived unit instead of as an SI unit, it makes more sense to conceptualize
420 the "kg" as if it were replaced by one of the proposed replacements for the SI mass symbol. If
421 one imagines that the "kg" were replaced by a symbol "P", then it is easier to conceptualize the
422 multiplier "m" as creating the proper unit "mP", and not the forbidden unit "mkg".

423 Table 16 shows all literals of UnitMultiplier.

424

Table 16 – Literals of ContingencyProfile::UnitMultiplier

literal	value	description
none	0	No multiplier or equivalently multiply by 1.

425

426 **3.15 UnitSymbol enumeration**

427 The derived units defined for usage in the CIM. In some cases, the derived unit is equal to an
428 SI unit. Whenever possible, the standard derived symbol is used instead of the formula for the
429 derived unit. For example, the unit symbol Farad is defined as "F" instead of "CPerV". In cases
430 where a standard symbol does not exist for a derived unit, the formula for the unit is used as
431 the unit symbol. For example, density does not have a standard symbol and so it is represented
432 as "kgPerm3". With the exception of the "kg", which is an SI unit, the unit symbols do not contain
433 multipliers and therefore represent the base derived unit to which a multiplier can be applied as
434 a whole.

435 Every unit symbol is treated as an unparseable text as if it were a single-letter symbol. The
436 meaning of each unit symbol is defined by the accompanying descriptive text and not by the
437 text contents of the unit symbol.

438 To allow the widest possible range of serializations without requiring special character handling,
439 several substitutions are made which deviate from the format described in IEC 80000-1. The
440 division symbol "/" is replaced by the letters "Per". Exponents are written in plain text after the
441 unit as "m3" instead of being formatted as "m" with a superscript of 3 or introducing a symbol
442 as in "m^3". The degree symbol "°" is replaced with the letters "deg". Any clarification of the
443 meaning for a substitution is included in the description for the unit symbol.

444 Non-SI units are included in list of unit symbols to allow sources of data to be correctly labelled
445 with their non-SI units (for example, a GPS sensor that is reporting numbers that represent feet
446 instead of meters). This allows software to use the unit symbol information correctly convert
447 and scale the raw data of those sources into SI-based units.

448 The integer values are used for harmonization with IEC 61850.

449 Table 17 shows all literals of UnitSymbol.

450

Table 17 – Literals of ContingencyProfile::UnitSymbol

literal	value	description
none	0	Dimension less quantity, e.g. count, per unit, etc.

451

452 **3.16 PerCent datatype**

453 Percentage on a defined base. For example, specify as 100 to indicate at the defined base.

454 Table 18 shows all attributes of PerCent.

455

Table 18 – Attributes of ContingencyProfile::PerCent

name	mult	type	description
value	0..1	Float	Normally 0 to 100 on a defined base.
unit	0..1	UnitSymbol	(const=none)
multiplier	0..1	UnitMultiplier	(const=none)

456

457 **3.17 Boolean primitive**

458 A type with the value space "true" and "false".

459 **3.18 Float primitive**

460 A floating point number. The range is unspecified and not limited.

461 **3.19 String primitive**

462 A string consisting of a sequence of characters. The character encoding is UTF-8. The string

463 length is unspecified and unlimited.

464

465

466

Annex A (informative): Sample data

A.1 General

468 This Annex is designed to illustrate the profile by using fragments of sample data. It is not meant
469 to be a complete set of examples covering all possibilities of using the profile. Defining a
470 complete set of test data is considered a separate activity to be performed for the purpose of
471 setting up interoperability testing and conformity related to this profile.

A.2 Sample instance data

473 Test data files are available in the CIM EG SharePoint.