



European Network of  
Transmission System Operators  
for Electricity

---

# MONITORING AREA PROFILE SPECIFICATION

---

2024-10-16

---

ICTC APPROVED  
VERSION 2.3.1

1 Copyright notice:

2 **Copyright © ENTSO-E. All Rights Reserved.**

3 This document and its whole translations may be copied and furnished to others, and derivative  
4 works that comment on or otherwise explain it or assist in its implementation may be prepared,  
5 copied, published and distributed, in whole or in part, without restriction of any kind, provided  
6 that the above copyright notice and this paragraph are included on all such copies and  
7 derivative works. However, this document itself may not be modified in any way, except for  
8 literal and whole translation into languages other than English and under all circumstances, the  
9 copyright notice or references to ENTSO-E may not be removed.

10 This document and the information contained herein is provided on an "as is" basis.

11 **ENTSO-E DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT**  
12 **LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT**  
13 **INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR**  
14 **FITNESS FOR A PARTICULAR PURPOSE.**

15 **This document is maintained by the ENTSO-E CIM WG. Comments or remarks are to be**  
16 **provided at [cim@entsoe.eu](mailto:cim@entsoe.eu)**

17 **NOTE CONCERNING WORDING USED IN THIS DOCUMENT**

18 The force of the following words is modified by the requirement level of the document in which  
19 they are used.

- 20 • **SHALL:** This word, or the terms "REQUIRED" or "MUST", means that the definition is an  
21 absolute requirement of the specification.
- 22 • **SHALL NOT:** This phrase, or the phrase "MUST NOT", means that the definition is an  
23 absolute prohibition of the specification.
- 24 • **SHOULD:** This word, or the adjective "RECOMMENDED", means that there may exist valid  
25 reasons in particular circumstances to ignore a particular item, but the full implications must  
26 be understood and carefully weighed before choosing a different course.
- 27 • **SHOULD NOT:** This phrase, or the phrase "NOT RECOMMENDED", means that there may  
28 exist valid reasons in particular circumstances when the particular behaviour is acceptable  
29 or even useful, but the full implications should be understood and the case carefully weighed  
30 before implementing any behaviour described with this label.
- 31 • **MAY:** This word, or the adjective "OPTIONAL", means that an item is truly optional.

32

33

## Revision History

Version	Date	Paragraph	Comments
2.2.0	2023-03-24		For review.
2.2.0	2023-04-20		For ICTC approval.
2.3.0-alpha	2024-03-20		For CIM WG review.
2.3.1-alpha	2024-09-07		For CIM WG review.

34	<b>CONTENTS</b>		
35	Copyright notice:.....		2
36	Revision History.....		3
37	CONTENTS .....		4
38	1 Introduction .....		6
39	2 Application profile specification .....		6
40	2.1 Version information .....		6
41	2.2 Constraints naming convention .....		6
42	2.3 Profile constraints .....		7
43	2.4 Metadata.....		10
44	2.4.1 Constraints .....		10
45	2.4.2 Reference metadata .....		10
46	3 Detailed Profile Specification .....		10
47	3.1 General.....		10
48	3.2 (NC) AreaBorderTerminal root class .....		11
49	3.3 (NC) ContingencyArea .....		12
50	3.4 (abstract) IdentifiedObject root class .....		12
51	3.5 (abstract,NC) InfluenceArea .....		13
52	3.6 (NC) MonitoringArea .....		13
53	3.7 (NC) ObservabilityArea .....		14
54	3.8 (abstract) PowerSystemResource .....		14
55	3.9 (abstract,NC) Region root class .....		15
56	3.10 (NC) SensitivityArea .....		15
57	3.11 (abstract,NC) SynchronousArea root class.....		15
58	3.12 (abstract,NC) SystemOperator root class .....		15
59	3.13 (abstract) Terminal root class.....		15
60	3.14 PerCent datatype .....		15
61	3.15 UnitMultiplier enumeration .....		16
62	3.16 UnitSymbol enumeration .....		16
63	3.17 String primitive.....		17
64	3.18 Float primitive .....		17
65	Annex A (informative): Sample data .....		18
66	A.1 General.....		18
67	A.2 Sample instance data.....		18
68			
69	<b>List of figures</b>		
70	Figure 1 – Class diagram MonitoringAreaProfile::Core .....		11
71	Figure 2 – Class diagram MonitoringAreaProfile::MonitoringArea .....		11
72			
73	<b>List of tables</b>		
74	Table 1 – Attributes of MonitoringAreaProfile::AreaBorderTerminal .....		11

75	Table 2 – Association ends of MonitoringAreaProfile::AreaBorderTerminal with other	
76	classes .....	12
77	Table 3 – Attributes of MonitoringAreaProfile::ContingencyArea .....	12
78	Table 4 – Association ends of MonitoringAreaProfile::ContingencyArea with other	
79	classes .....	12
80	Table 5 – Attributes of MonitoringAreaProfile::IdentifiedObject .....	12
81	Table 6 – Attributes of MonitoringAreaProfile::InfluenceArea .....	13
82	Table 7 – Association ends of MonitoringAreaProfile::InfluenceArea with other classes .....	13
83	Table 8 – Attributes of MonitoringAreaProfile::MonitoringArea .....	14
84	Table 9 – Association ends of MonitoringAreaProfile::MonitoringArea with other	
85	classes .....	14
86	Table 10 – Attributes of MonitoringAreaProfile::ObservabilityArea .....	14
87	Table 11 – Association ends of MonitoringAreaProfile::ObservabilityArea with other	
88	classes .....	14
89	Table 12 – Attributes of MonitoringAreaProfile::PowerSystemResource .....	15
90	Table 13 – Attributes of MonitoringAreaProfile::SensitivityArea .....	15
91	Table 14 – Association ends of MonitoringAreaProfile::SensitivityArea with other	
92	classes .....	15
93	Table 15 – Attributes of MonitoringAreaProfile::PerCent .....	16
94	Table 16 – Literals of MonitoringAreaProfile::UnitMultiplier .....	16
95	Table 17 – Literals of MonitoringAreaProfile::UnitSymbol .....	17
96		

## 97 1 Introduction

98 The monitoring area profile enables the exchange of monitoring area related information like  
99 the influence factors. These influence factors allow defining the observability area and external  
100 contingency list as detailed by Art 5.5 and Art 6.2 of CSA methodology.

101 For information, the observability area and the external contingency list influence factors are  
102 published in the [SO GL related deliverables in ENTSO-E webpage](#), under SO GL Art 75.1  
103 Methodology for coordinating operational security analysis.

## 104 2 Application profile specification

### 105 2.1 Version information

106 The content is generated from UML model file CIM17-2\_CGMES31v01\_PROF-  
107 20v02\_NC23v65\_MS10v01\_DES10v01.eap.

108 This edition is based on the IEC 61970 UML version 'IEC61970CIM17v40', dated '2020-08-24'.

- 109 - Title: Monitoring area Vocabulary
- 110 - Keyword: MA
- 111 - Description: This vocabulary is describing the monitoring area profile.
- 112 - Version IRI: <https://ap-voc.cim4.eu/MonitoringArea/2.3>
- 113 - Version info: 2.3.1
- 114 - Prior version:
- 115 - Conforms to: urn:iso:std:iec:61970-600-2:ed-1|urn:iso:std:iec:61970-301:ed-  
116 7:amd1|file:///iec61970cim17v40\_iec61968cim13v13a\_iec62325cim03v17a.eap|urn:iso:  
117 std:iec:61970-401:draft:ed-1|urn:iso:std:iec:61970-501:draft:ed-  
118 2|file:///CIM100\_CGMES31v01\_501-20v02\_NC23v62\_MM10v01.eap
- 119 - Identifier: urn:uuid:41075091-91f0-4b14-a5b8-93945aa528ed

120

### 121 2.2 Constraints naming convention

122 The naming of the rules shall not be used for machine processing. The rule names are just a  
123 string. The naming convention of the constraints is as follows.

124 "{rule.Type}:{rule.Standard}:{rule.Profile}:{rule.Property}:{rule.Name}"

125 where

126 rule.Type: C – for constraint; R – for requirement

127 rule.Standard: the number of the standard e.g. 301 for 61970-301, 456 for 61970-456, 13 for  
128 61968-13. 61970-600 specific constraints refer to 600 although they are related to one or  
129 combination of the 61970-450 series profiles. For NC profiles, NC is used.

130 rule.Profile: the abbreviation of the profile, e.g. TP for Topology profile. If set to "ALL" the  
131 constraint is applicable to all IEC 61970-600 profiles.

132 rule.Property: for UML classes, the name of the class, for attributes and associations, the name  
133 of the class and attribute or association end, e.g. EnergyConsumer, IdentifiedObject.name, etc.  
134 If set to "NA" the property is not applicable to a specific UML element.

135 rule.Name: the name of the rule. It is unique for the same property.

136 Example: C:600:ALL:IdentifiedObject.name:stringLength

### 137 **2.3 Profile constraints**

138 This clause defines requirements and constraints that shall be fulfilled by applications that  
139 conform to this document.

140 This document is the master for rules and constraints tagged "NC". For the sake of self-  
141 containment, the list below also includes a copy of the relevant rules from IEC 61970-452,  
142 tagged "452".

- 143 • C:452:ALL:NA:datatypes

144 According to 61970-501, datatypes are not exchanged in the instance data. The  
145 UnitMultiplier is 1 in cases none value is specified in the profile.

- 146 • R:452:ALL:NA:exchange

147 Optional and required attributes and associations must be imported and exported if they  
148 are in the model file prior to import.

- 149 • R:452:ALL:NA:exchange1

150 If an optional attribute does not exist in the imported file, it does not have to be exported  
151 in case exactly the same data set is exported, i.e. the tool is not obliged to automatically  
152 provide this attribute. If the export is resulting from an action by the user performed after  
153 the import, e.g. data processing or model update the export can contain optional  
154 attributes.

- 155 • R:452:ALL:NA:exchange2

156 In most of the profiles the selection of optional and required attributes is made so as to  
157 ensure a minimum set of required attributes without which the exchange does not fulfil  
158 its basic purpose. Business processes governing different exchanges can require  
159 mandatory exchange of certain optional attributes or associations. Optional and required  
160 attributes and associations shall therefore be supported by applications which claim  
161 conformance with certain functionalities of the IEC 61970-452. This provides flexibility  
162 for the business processes to adapt to different business requirements and base the  
163 exchanges on IEC 61970-452 compliant applications.

- 164 • R:452:ALL:NA:exchange3

165 An exporter may, at his or her discretion, produce a serialization containing additional  
166 class data described by the CIM Schema but not required by this document provided  
167 these data adhere to the conventions established in Clause 5.

- 168 • R:452:ALL:NA:exchange4

169 From the standpoint of the model import used by a data recipient, the document  
170 describes a subset of the CIM that importing software shall be able to interpret in order  
171 to import exported models. Data providers are free to exceed the minimum requirements  
172 described herein as long as their resulting data files are compliant with the CIM Schema  
173 and the conventions established in Clause 5. The document, therefore, describes  
174 additional classes and class data that, although not required, exporters will, in all  
175 likelihood, choose to include in their data files. The additional classes and data are  
176 labelled as required (cardinality 1..1) or as optional (cardinality 0..1) to distinguish them  
177 from their required counterparts. Please note, however, that data importers could

- 178 potentially receive data containing instances of any and all classes described by the  
179 CIM Schema.
- 180 • R:452:ALL:NA:cardinality
- 181 The cardinality defined in the CIM model shall be followed, unless a more restrictive  
182 cardinality is explicitly defined in this document. For instance, the cardinality on the  
183 association between VoltageLevel and BaseVoltage indicates that a VoltageLevel shall  
184 be associated with one and only one BaseVoltage, but a BaseVoltage can be associated  
185 with zero to many VoltageLevels.
- 186 • R:452:ALL:NA:associations
- 187 Associations between classes referenced in this document and classes not referenced  
188 here are not required regardless of cardinality.
- 189 • R:452:ALL:IdentifiedObject.name:rule
- 190 The attribute “name” inherited by many classes from the abstract class IdentifiedObject  
191 is not required to be unique. It must be a human readable identifier without additional  
192 embedded information that would need to be parsed. The attribute is used for purposes  
193 such as User Interface and data exchange debugging. The MRID defined in the data  
194 exchange format is the only unique and persistent identifier used for this data exchange.  
195 The attribute IdentifiedObject.name is, however, always required for CoreEquipment  
196 profile and Short Circuit profile.
- 197 • R:452:ALL:IdentifiedObject.description:rule
- 198 The attribute “description” inherited by many classes from the abstract class  
199 IdentifiedObject must contain human readable text without additional embedded  
200 information that would need to be parsed.
- 201 • R:452:ALL:NA:uniqueIdentifier
- 202 All IdentifiedObject-s shall have a persistent and globally unique identifier (Master  
203 Resource Identifier - mRID).
- 204 • R:452:ALL:NA:unitMultiplier
- 205 For exchange of attributes defined using CIM Data Types (ActivePower, Susceptance,  
206 etc.) a unit multiplier of 1 is used if the UnitMultiplier specified in this document is “none”.
- 207 • C:452:ALL:IdentifiedObject.name:stringLength
- 208 The string IdentifiedObject.name has a maximum of 128 characters.
- 209 • C:452:ALL:IdentifiedObject.description:stringLength
- 210 The string IdentifiedObject.description is maximum 256 characters.
- 211 • C:452:ALL:NA:float
- 212 An attribute that is defined as float (e.g. has a type Float or a type which is a Datatype  
213 with .value attribute of type Float) shall support ISO/IEC 60559:2020 for floating-point  
214 arithmetic using single precision floating point. A single precision float supports 7  
215 significant digits where the significant digits are described as an integer, or a decimal  
216 number with 6 decimal digits. Two float values are equal when the significant with 7  
217 digits are identical, e.g. 1234567 is equal 1.234567E6 and so are 1.2345678 and  
218 1.234567E0.



- 219       • R:NC:ALL:Region:reference
- 220       The reference to the Region is normally a reference to the capacity calculation region,  
221       which is identified by “Y” EIC code of the capacity calculation region.
- 222       • R:NC:ALL:SystemOperator:reference
- 223       The reference to the System Operator is normally identified by “X” EIC code of TSO.
- 224       • C:NC:MA:MonitoringArea:associations
- 225       MonitoringArea can have either of the following associations, i.e., not both of them:  
226       nc:MonitoringArea.Region or nc:MonitoringArea.SystemOperator.
- 227       • R:NC:ALL:NA:serialization
- 228       The profiles are defined in the EnterpriseArchitect application and have multiple artifacts  
229       that describe them. The main artifacts are:
- 230       1) the EAP file (EnterpriseArchitect project file),  
231       2) the profiles’ specification document and  
232       3) the application profiles (RDFS and SHACL).
- 233       Due to the complexity of the profiles, there are various cross profile associations that,  
234       from profiling and profile maintenance point of view, it is not practical to include the  
235       complete inheritance structure in all profiles. If this is done the documentation provided  
236       for all profiles would also include duplicated information on the description of classes  
237       defined in other profiles. The following cases are often observed in profiles:
- 238       ○ Case 1: An association end refers to an abstract class
- 239       ○ Case 2: An abstract class (stereotyped with “Description”) has an association  
240       (direction to another class)
- 241       ○ Case 3: An abstract class (not stereotyped with “Description”) has an  
242       association (direction to another class)
- 243       ○ Case 4: An abstract class has attributes and subclasses are not in the profile
- 244       In all cases, the datasets shall only include the subtypes of the abstract classes with  
245       the related properties (i.e. association or attributes) defined in the profile. The  
246       information is taken from either canonical model or the profiles where complete  
247       (expected) inheritance structure for the related abstract class is described. SHACL  
248       based constraints include constraints only for the concrete classes that are subtypes of  
249       the abstract class in the profile, and this can be used to inform which are the concrete  
250       classes expected in a dataset that conforms to this profile.
- 251       It should be taken into account that this approach deviates from MVAL5 (IEC 61970-  
252       600-1:2021), which creates multiple inheritance at serialization. For instance, with this  
253       more explicit exchange the serialization of the association between abstract class  
254       Equipment and abstract class Circuit for a PowerTransformer will be serialized as  
255       follows:
- 256       ○ for association
- 257       <cim:PowerTransformer rdf:about="\_c328f787-bc17-47ad-a59f-6ba7133340d0">
- 258        <nc:Equipment.Circuit rdf:resource="#\_9ced16ac-d076-4ef9-a241-a998a579e77b"/>
- 259       </cim:PowerTransformer>
- 260       ○ for attribute
- 261       <cim:ACLineSegment rdf:about="\_04f681aa-6999-4fb3-9775-aca5eb7ceff">

262                    <cim:Equipment.inService>true</cim:Equipment.inService>

263                    </cim:ACLineSegment>

264                    The usage of rdf:ID or rdf:about depends on the stereotype of the class. rdf:about is  
265                    used if the class has the stereotype "Description".

266                    An example of not allowed serialization, as the Equipment is an abstract class

267                    <cim:Equipment rdf:about="\_c328f787-bc17-47ad-a59f-6ba7133340d0">

268                        <nc:Equipment.Circuit rdf:resource="#\_9ced16ac-d076-4ef9-a241-a998a579e77b"/>

269                    </cim:Equipment>

270

271

## 272     **2.4     Metadata**

273     ENTSO-E agreed to extend the header and metadata definitions by IEC 61970-552 Ed2. This  
274     new header definitions rely on W3C recommendations which are used worldwide and are  
275     positively recognised by the European Commission. The new definitions of the header mainly  
276     use Provenance ontology (PROV-O), Time Ontology and Data Catalog Vocabulary (DCAT). The  
277     global new header applicable for this profile is included in the metadata and document header  
278     specification document.

279     The header vocabulary contains all attributes defined in IEC 61970-552. This is done only for  
280     the purpose of having one vocabulary for header and to ensure transition for data exchanges  
281     that are using IEC 61970-552:2016 header. This profile does not use IEC 61970-552:2016  
282     header attributes and relies only on the extended attributes.

### 283     **2.4.1     Constraints**

284     The identification of the constraints related to the metadata follows the same convention for  
285     naming of the constraints as for profile constraints.

- 286             • R:NC:ALL:wasAttributedTo:usage

287                    The prov:wasAttributedTo should normally be the "X" EIC code of the actor or their URI  
288                    (prov:Agent).

289


### 290     **2.4.2     Reference metadata**

291     The header defined for this profile requires availability of a set of reference metadata. For  
292     instance, the attribute prov:wasGeneratedBy requires a reference to an activity which produced  
293     the model or the related process. The activities are defined as reference metadata and their  
294     identifiers are referenced from the header to enable the receiving entity to retrieve the "static"  
295     (reference) information that is not modified frequently. This approach imposes a requirement  
296     that both the sending entity and the receiving entity have access to a unique version of the  
297     reference metadata. Therefore, each business process shall define which reference metadata  
298     is used and where it is located.

## 299     **3     Detailed Profile Specification**

### 300     **3.1     General**

301     This package contains monitoring area profile.




302

303

**Figure 1 – Class diagram MonitoringAreaProfile::Core**

304

Figure 1: The diagram shows classes from Base CIM used in the profile.



305

306

**Figure 2 – Class diagram MonitoringAreaProfile::MonitoringArea**

307 Figure 2: The diagram shows monitoring area related classes.

308 **3.2 (NC) AreaBorderTerminal root class**

309 Area border terminal defines the terminals that are defining a monitoring area.

310 Table 1 shows all attributes of AreaBorderTerminal.

311

**Table 1 – Attributes of MonitoringAreaProfile::AreaBorderTerminal**

name	mult	type	description
mRID	1..1	<a href="#">String</a>	Master resource identifier issued by a model authority. The mRID is unique within an exchange context. Global uniqueness is easily achieved by using a UUID, as specified in RFC 4122, for the mRID. The use of UUID is strongly recommended.  For CIMXML data files in RDF syntax conforming to IEC 61970-552, the mRID is mapped to rdf:ID or rdf:about attributes that identify CIM object elements.

312

313 Table 2 shows all association ends of AreaBorderTerminal with other classes.

314 **Table 2 – Association ends of MonitoringAreaProfile::AreaBorderTerminal with other**  
315 **classes**

mult from	name	mult to	type	description
0..*	MonitoringArea	1..1	<a href="#">MonitoringArea</a>	(NC) The MonitoringArea defined by this AreaBorderTerminal.
0..*	Terminal	1..1	<a href="#">Terminal</a>	(NC) The Terminal that is part of an AreaBorderTerminal.

316

### 317 3.3 (NC) ContingencyArea

318 Inheritance path = [InfluenceArea](#) : [MonitoringArea](#) : [PowerSystemResource](#) : [IdentifiedObject](#)

319 A monitoring area that defines the required contingency elements. This includes elements that  
320 are part of the external contingency list.

321 Table 3 shows all attributes of ContingencyArea.

322 **Table 3 – Attributes of MonitoringAreaProfile::ContingencyArea**

name	mult	type	description
identificationInfluenceFactor	0..1	<a href="#">PerCent</a>	(NC) inherited from: <a href="#">InfluenceArea</a>
filteringInfluenceFactor	0..1	<a href="#">PerCent</a>	(NC) inherited from: <a href="#">InfluenceArea</a>
voltageInfluenceFactor	0..1	<a href="#">PerCent</a>	(NC) inherited from: <a href="#">InfluenceArea</a>
description	0..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>
mRID	1..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>
name	1..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>

323

324 Table 4 shows all association ends of ContingencyArea with other classes.

325 **Table 4 – Association ends of MonitoringAreaProfile::ContingencyArea with other**  
326 **classes**

mult from	name	mult to	type	description
0..*	SynchronousArea	0..1	<a href="#">SynchronousArea</a>	(NC) inherited from: <a href="#">MonitoringArea</a>
0..*	SystemOperator	0..1	<a href="#">SystemOperator</a>	(NC) inherited from: <a href="#">MonitoringArea</a>
0..*	Region	0..1	<a href="#">Region</a>	(NC) inherited from: <a href="#">MonitoringArea</a>

327

### 328 3.4 (abstract) IdentifiedObject root class

329 This is a root class to provide common identification for all classes needing identification and  
330 naming attributes.

331 Table 5 shows all attributes of IdentifiedObject.

332 **Table 5 – Attributes of MonitoringAreaProfile::IdentifiedObject**

name	mult	type	description
description	0..1	<a href="#">String</a>	The description is a free human readable text describing or naming the object. It may be non unique and may not correlate to a naming hierarchy.
mRID	1..1	<a href="#">String</a>	Master resource identifier issued by a model authority. The mRID is unique within an exchange context. Global uniqueness is easily achieved by using a UUID, as specified in RFC

name	mult	type	description
			4122, for the mRID. The use of UUID is strongly recommended. For CIMXML data files in RDF syntax conforming to IEC 61970-552, the mRID is mapped to rdf:ID or rdf:about attributes that identify CIM object elements.
name	1..1	<a href="#">String</a>	The name is any free human readable and possibly non unique text naming the object.

333

334 **3.5 (abstract,NC) InfluenceArea**335 Inheritance path = [MonitoringArea](#) : [PowerSystemResource](#) : [IdentifiedObject](#)

336 Influence area is a monitoring area that is defined by calculating the equipment that is affected

337 by the influence factors.

338 Table 6 shows all attributes of InfluenceArea.

339

**Table 6 – Attributes of MonitoringAreaProfile::InfluenceArea**

name	mult	type	description
identificationInfluenceFactor	0..1	<a href="#">PerCent</a>	(NC) Power flow identification influence factor of a network element that is normalised in order to take into account potential impacts induced by differences in Permanently Admissible Transmission Loading (PATL) values. This is referred as identification influence threshold in CSA methodology. The allowed value range is [0,100].
filteringInfluenceFactor	0..1	<a href="#">PerCent</a>	(NC) Power flow filtering influence factor of a network element not normalised. This is referred as power flow influence threshold in CSA methodology. The allowed value range is [0,100].
voltageInfluenceFactor	0..1	<a href="#">PerCent</a>	(NC) Voltage influence factor of a network element as defined in the CSA methodology. The allowed value range is [0,100].
description	0..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>
mRID	1..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>
name	1..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>

340

341 Table 7 shows all association ends of InfluenceArea with other classes.

342 **Table 7 – Association ends of MonitoringAreaProfile::InfluenceArea with other classes**

mult from	name	mult to	type	description
0..*	SynchronousArea	0..1	<a href="#">SynchronousArea</a>	(NC) inherited from: <a href="#">MonitoringArea</a>
0..*	SystemOperator	0..1	<a href="#">SystemOperator</a>	(NC) inherited from: <a href="#">MonitoringArea</a>
0..*	Region	0..1	<a href="#">Region</a>	(NC) inherited from: <a href="#">MonitoringArea</a>

343

344 **3.6 (NC) MonitoringArea**345 Inheritance path = [PowerSystemResource](#) : [IdentifiedObject](#)346 A coherent part of the interconnected electrical power system, that includes the system  
347 operators' responsibility area and the surrounding parts of other system operators' responsibility  
348 area, that need to be monitored for security assessment.

349 Table 8 shows all attributes of MonitoringArea.

350

**Table 8 – Attributes of MonitoringAreaProfile::MonitoringArea**

name	mult	type	description
description	0..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>
mRID	1..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>
name	1..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>

351

352

Table 9 shows all association ends of MonitoringArea with other classes.

353

**Table 9 – Association ends of MonitoringAreaProfile::MonitoringArea with other classes**

mult from	name	mult to	type	description
0..*	SynchronousArea	0..1	<a href="#">SynchronousArea</a>	(NC) The synchronous area that has this monitoring area.
0..*	SystemOperator	0..1	<a href="#">SystemOperator</a>	(NC) The system operator that operates this monitoring area.
0..*	Region	0..1	<a href="#">Region</a>	(NC) Region that has monitoring areas.

354

355

**3.7 (NC) ObservabilityArea**

356

Inheritance path = [MonitoringArea](#) : [PowerSystemResource](#) : [IdentifiedObject](#)

357

A monitoring area that is given by a real time measurement.

358

Table 10 shows all attributes of ObservabilityArea.

359

**Table 10 – Attributes of MonitoringAreaProfile::ObservabilityArea**

name	mult	type	description
description	0..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>
mRID	1..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>
name	1..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>

360

361

Table 11 shows all association ends of ObservabilityArea with other classes.

362

**Table 11 – Association ends of MonitoringAreaProfile::ObservabilityArea with other classes**

363

mult from	name	mult to	type	description
0..*	SynchronousArea	0..1	<a href="#">SynchronousArea</a>	(NC) inherited from: <a href="#">MonitoringArea</a>
0..*	SystemOperator	0..1	<a href="#">SystemOperator</a>	(NC) inherited from: <a href="#">MonitoringArea</a>
0..*	Region	0..1	<a href="#">Region</a>	(NC) inherited from: <a href="#">MonitoringArea</a>

364

365

**3.8 (abstract) PowerSystemResource**

366

Inheritance path = [IdentifiedObject](#)

367

A power system resource (PSR) can be an item of equipment such as a switch, an equipment container containing many individual items of equipment such as a substation, or an organisational entity such as sub-control area. Power system resources can have measurements associated.

370

Table 12 shows all attributes of PowerSystemResource.

372 **Table 12 – Attributes of MonitoringAreaProfile::PowerSystemResource**

name	mult	type	description
description	0..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>
mRID	1..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>
name	1..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>

373

374 **3.9 (abstract,NC) Region root class**

375 A region where the system operator belongs to.

376 **3.10 (NC) SensitivityArea**377 Inheritance path = [InfluenceArea](#) : [MonitoringArea](#) : [PowerSystemResource](#) : [IdentifiedObject](#)

378 A monitoring area that defines the required observability area given by the sensitivity factors.

379 Table 13 shows all attributes of SensitivityArea.

380 **Table 13 – Attributes of MonitoringAreaProfile::SensitivityArea**

name	mult	type	description
identificationInfluenceFactor	0..1	<a href="#">PerCent</a>	(NC) inherited from: <a href="#">InfluenceArea</a>
filteringInfluenceFactor	0..1	<a href="#">PerCent</a>	(NC) inherited from: <a href="#">InfluenceArea</a>
voltageInfluenceFactor	0..1	<a href="#">PerCent</a>	(NC) inherited from: <a href="#">InfluenceArea</a>
description	0..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>
mRID	1..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>
name	1..1	<a href="#">String</a>	inherited from: <a href="#">IdentifiedObject</a>

381

382 Table 14 shows all association ends of SensitivityArea with other classes.

383 **Table 14 – Association ends of MonitoringAreaProfile::SensitivityArea with other classes**

384

mult from	name	mult to	type	description
0..*	SynchronousArea	0..1	<a href="#">SynchronousArea</a>	(NC) inherited from: <a href="#">MonitoringArea</a>
0..*	SystemOperator	0..1	<a href="#">SystemOperator</a>	(NC) inherited from: <a href="#">MonitoringArea</a>
0..*	Region	0..1	<a href="#">Region</a>	(NC) inherited from: <a href="#">MonitoringArea</a>

385

386 **3.11 (abstract,NC) SynchronousArea root class**387 A synchronous area is an electrical area covered by interconnect with a common system  
388 frequency in a steady-state.389 **3.12 (abstract,NC) SystemOperator root class**

390 System operator.

391 **3.13 (abstract) Terminal root class**392 An AC electrical connection point to a piece of conducting equipment. Terminals are connected  
393 at physical connection points called connectivity nodes.394 **3.14 PerCent datatype**

395 Percentage on a defined base. For example, specify as 100 to indicate at the defined base.

396 Table 15 shows all attributes of PerCent.

397

**Table 15 – Attributes of MonitoringAreaProfile::PerCent**

name	mult	type	description
value	0..1	<a href="#">Float</a>	Normally 0 to 100 on a defined base.
unit	0..1	<a href="#">UnitSymbol</a>	(const=none)
multiplier	0..1	<a href="#">UnitMultiplier</a>	(const=none)

398

**3.15 UnitMultiplier enumeration**

399 The unit multipliers defined for the CIM. When applied to unit symbols, the unit symbol is  
400 treated as a derived unit. Regardless of the contents of the unit symbol text, the unit symbol  
401 shall be treated as if it were a single-character unit symbol. Unit symbols should not contain  
402 multipliers, and it should be left to the multiplier to define the multiple for an entire data type.

403 For example, if a unit symbol is "m2Pers" and the multiplier is "k", then the value is  $k(m^{**2}/s)$ ,  
404 and the multiplier applies to the entire final value, not to any individual part of the value. This  
405 can be conceptualized by substituting a derived unit symbol for the unit type. If one imagines  
406 that the symbol "P" represents the derived unit "m2Pers", then applying the multiplier "k" can  
407 be conceptualized simply as "kP".

408 For example, the SI unit for mass is "kg" and not "g". If the unit symbol is defined as "kg", then  
409 the multiplier is applied to "kg" as a whole and does not replace the "k" in front of the "g". In  
410 this case, the multiplier of "m" would be used with the unit symbol of "kg" to represent one gram.  
411 As a text string, this violates the instructions in IEC 80000-1. However, because the unit symbol  
412 in CIM is treated as a derived unit instead of as an SI unit, it makes more sense to conceptualize  
413 the "kg" as if it were replaced by one of the proposed replacements for the SI mass symbol. If  
414 one imagines that the "kg" were replaced by a symbol "P", then it is easier to conceptualize the  
415 multiplier "m" as creating the proper unit "mP", and not the forbidden unit "mkg".

416 Table 16 shows all literals of UnitMultiplier.

417

**Table 16 – Literals of MonitoringAreaProfile::UnitMultiplier**

literal	value	description
none	0	No multiplier or equivalently multiply by 1.

418

**3.16 UnitSymbol enumeration**

419 The derived units defined for usage in the CIM. In some cases, the derived unit is equal to an  
420 SI unit. Whenever possible, the standard derived symbol is used instead of the formula for the  
421 derived unit. For example, the unit symbol Farad is defined as "F" instead of "CPerV". In cases  
422 where a standard symbol does not exist for a derived unit, the formula for the unit is used as  
423 the unit symbol. For example, density does not have a standard symbol and so it is represented  
424 as "kgPerm3". With the exception of the "kg", which is an SI unit, the unit symbols do not contain  
425 multipliers and therefore represent the base derived unit to which a multiplier can be applied as  
426 a whole.

427 Every unit symbol is treated as an unparseable text as if it were a single-letter symbol. The  
428 meaning of each unit symbol is defined by the accompanying descriptive text and not by the  
429 text contents of the unit symbol.

430 To allow the widest possible range of serializations without requiring special character handling,  
431 several substitutions are made which deviate from the format described in IEC 80000-1. The  
432 division symbol "/" is replaced by the letters "Per". Exponents are written in plain text after the  
433 unit as "m3" instead of being formatted as "m" with a superscript of 3 or introducing a symbol  
434 as in "m^3". The degree symbol "°" is replaced with the letters "deg". Any clarification of the  
435 meaning for a substitution is included in the description for the unit symbol.

436 Non-SI units are included in list of unit symbols to allow sources of data to be correctly labelled  
437 with their non-SI units (for example, a GPS sensor that is reporting numbers that represent feet  
438 instead of meters). This allows software to use the unit symbol information correctly convert  
439 and scale the raw data of those sources into SI-based units.

440



442 The integer values are used for harmonization with IEC 61850.

443 Table 17 shows all literals of UnitSymbol.

444 **Table 17 – Literals of MonitoringAreaProfile::UnitSymbol**

literal	value	description
none	0	Dimension less quantity, e.g. count, per unit, etc.

445

446 **3.17 String primitive**

447 A string consisting of a sequence of characters. The character encoding is UTF-8. The string  
448 length is unspecified and unlimited.

449 **3.18 Float primitive**

450 A floating point number. The range is unspecified and not limited.

451

452

453

## **Annex A (informative): Sample data**

### **A.1 General**

455 This Annex is designed to illustrate the profile by using fragments of sample data. It is not meant  
456 to be a complete set of examples covering all possibilities of using the profile. Defining a  
457 complete set of test data is considered a separate activity to be performed for the purpose of  
458 setting up interoperability testing and conformity related to this profile.

### **A.2 Sample instance data**

460 Test data files are available in the CIM EG SharePoint.